


Slinger[®]

USER GUIDE of
HOW TO CHARGE YOUR BATTERY PACK

JULY 2020



WARNING:

Please **Switch Off** Slinger T-One Launcher first.

Step 1:

Unscrew 4 screws that fix Battery Drawer by hand

Battery Drawer



Step 2:

In case screws missing, screw them back to its holes.
Or store 4 screws at Left/ Right Pockets of Bag.






Battery Drawer



Step 3:

Take out Battery Drawer a little bit



Battery Drawer

Step 4:

Disconnect Battery Wire with
"Launcher Connector"

 Launcher Connector





Step 5:

Take Battery Drawer out completely.
Open Cover of “Charger Connector”.

Battery Drawer



Charger Connector






Step 6:



Please make sure Adaptor is plugged well with Power Charger.

Plug Power Charger into “Charger Connector”.

- LED on Power Charger in **Red**: Battery is charging
- LED on Power Charger in **Green**: Battery is full charge



Step 7:

After Battery full charge, disconnect Charger Wire.
Open cover of "Launcher Connector".

Unscrew 4 screws that fix Battery Drawer by hand.
Place Battery Drawer into Launcher Structure slightly and connect Battery Wire.





Step 8:

Place Battery Drawer into Launcher Structure completely.
Screw these with Battery Drawer well.

Battery Drawer